



Lötstationen HF Serie:

Änderung des Betriebsmodus / *Changing Operating Mode*

Durch Änderung des Betriebsmodus lässt sich die Station in verschiedenen Temperaturbereichen betreiben.

By changing the operation mode, the station can be used with different temperature settings.

Warnung: Langer Betrieb der Station mit hohen Temperaturen (über 400°C) kann die Lötspitze und das Heizelement oxidieren und deren Lebensdauer verkürzen!

Warning: *long-term operating with high temperature (over 400 °C) can cause oxidation on the heater and tips, which will shorten the lifetime!*

Operating Modes / Betriebsmodi

Operating mode	Applicable soldering iron type	Adjustable temp range	Suitable for high frequency soldering iron type	Remark
0	High-frequency soldering iron	200~420°C	60W	Sleeping and automatic shutdown function
1	High-frequency soldering iron	200~420°C	100,150,180W	
2	High-frequency soldering iron (special large one)	200~420°C	60, 100,150,180W	
3	Special application	50~600°C	100,150,180W	
4	High-frequency soldering iron	50~240°C	60W	
5	High-frequency soldering iron	50~240°C	100,150,180W	
6	High-frequency soldering iron	200~480°C	60W	
7	High-frequency soldering iron	200~480°C	100,150,180W	
0.	High-frequency soldering iron	200~420°C	60W	
1.	High-frequency soldering iron	200~420°C	100,150,180W	
2.	High-frequency soldering iron (special large one)	200~420°C	60, 100,150,180W	
3.	Special application	50~600°C	100,150,180W	
4.	High-frequency soldering iron	50~420°C	60W	
5.	High-frequency soldering iron	50~420°C	100,150,180W	
6.	High-frequency soldering iron	200~480°C	60W	
7.	High-frequency soldering iron	200~480°C	100,150,180W	



D- Änderung des Betriebsmodus

Station ausschalten

Tasten „+“ und „-“ gleichzeitig drücken und halten

Station einschalten Tasten „+“ und „-“ loslassen

Display zeigt „C“

Taste „*“ drücken

Display zeigt „ - - „

Passwort eingeben

Standardpasswort: 0 0 0

Eingabe der Ziffer mit „+“ oder „-“ und mit „*“ Taste bestätigen,

für alle drei Ziffern wiederholen

(siehe auch Handbuch: Passworteingabe)

Display zeigt „OR“

Innerhalb 4 Sekunden Tasten „+“ und „-“ gleichzeitig drücken.

Display zeigt eine Ziffer zwischen **1** und **7** bzw. zwischen **1.** und **7.**

Hinweis: der Punkt hinter der Zahl deutet auf die automatische Abschaltfunktion hin

Mit „+“ oder „-“ den Wert auf den gewünschten Betriebsmodus einstellen

Mit „*“ Taste bestätigen.



GB- Changing Operating Mode

Switch off station

Press and hold keys „+“ and „-“ together

Switch on station, release keys „+“ and „-“

Display shows „C“

Press key: „*“

Display shows „ - - „

Input password

standard password: 0 0 0

input digits with „+“ or „-“ and confirm with „“ key*

repeat for all three digits

(please refer also to manual : password setup)

Display shows „OR“

With in 4 seconds press keys „+“ and „-“ together

Display shows a digit between 1 und 7 or between 1. und 7.

Remark: *the dot behind the number indicates the automatic shutoff function*

Adjust the digit to the desired operation mode with „+“ or „-“ key

Confirm with „*“ key